



# ELECTRIC WIDE NECK BOTTLE AND FOOD WARMER MULTI-PURPOSE WARMER WITH JUICER AND FEEDING BOWL



## FITS ALL BRANDS AND SIZES OF BABY BOTTLES

## **IMPORTANT:**

- 1. BREAST MILK IS THE BEST FOOD FOR YOUR BABY.
- 2. This product is not always sterile and might contain microorganisms. It must be prepared, sterilised and used appropriately.
- 3. If you are breast feeding your baby, using a feeding bottle and teat may interfere with the baby's natural way of suckling your breast
- 4. Make sure there is water in the bottle warmer unit at all times. Never let the unit run dry as it will damage the unit.
- 5. Never switch on the unit without water in the warmer unit.
- 6. Water must not be filled over the maximum level indicator found in the unit.
- 7. Always check milk or baby food temperature before feeding. Hot food / fluids will burn baby.
- 8. Never immerse the bottle warmer unit in water.
- 9. Pour out excess water after each use.
- 10. Clean the unit with damp cloth only. The unit is not dishwasher safe.
- 11. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a qualified person in order to avoid any hazard.

## **INSTRUCTIONS:**

Before plugging the unit into a main socket, make sure the warmer unit is switched to the off position. Always check if there is enough water in the unit. Always test liquid / food temperature before giving to baby.

- Pour water into the warmer unit.
- Place milk bottle into the water OR place food into plastic bowl supplied.
- Take note not to let the water overflow when placing bottle in the unit.
- Insert the plug and turn the switch / knob to the desired function / temperature.
- The red pilot light will go on and will switch off automatically when desired temperature is reached. After use, switch off and unplug the unit.

## **TEMPERATURE RANGE AND FUNCTION:**

Temperature	Use
<b>40</b> °C	Constant temperature for preparing liquid food (milk, etc.)
<b>70</b> ℃	Heating baby food or to keep baby food warm
<b>100</b> ℃	Quick heat function (from $4^{\circ}C$ - $37^{\circ}C$ within 8 minutes)
<b>100</b> ℃	Sterilize teats and pacifiers / dummies by putting them into the warmer unit and covering with lid.

#### Keeping warm:

To keep milk warm in baby bottle, add water into the warmer unit, turn the knob to  $\frac{A}{400}$ , reaching about 40°C.

#### Heating:

Heating up baby food, add water, turn knob to 💮 , reaching about 70°C.

#### Quick heat function:

Add 8-10ml water to the warmer unit, set the knob to  $100^{\circ}C_{\infty}$  It will heat up milk from  $4^{\circ}C-37^{\circ}C$  within 8-10 minutes.

#### Sterilizing:

Add 20-30ml water to the warmer unit, place teats / dummies into warmer unit, set the switch to  $100^{\circ}$ C, Water will start to boil and will sterilize for around 10 minutes.

**IMPORTANT:** Make sure the water in unit does not evaporate.

#### Juicer function:

This unit comes with a manual operated juicer to squeeze out fresh juice by hand, supplying more nutrition to baby.

## UWARNING:

- This is not a toy. Keep away from baby / children, as this unit contains boiling water during use. Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance be a person responsible for their safety.
- When in use, ensure that there is enough water in the unit at all times.
- Always test liquid / food temperature before giving to baby.
- Pull out the plug from wall socket after using the warmer unit.
- Pour out the water after using the warmer unit.
- Clean warmer unit only with damp cloth, while the unit is unplugged.
- Do not immerse warmer unit into water.
- Food should not be heated for long periods.
- Throw away unused milk or food.
- Warmer unit for household and indoor use only (AC mains only).
- Do not dismantle the warmer unit.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
- The warmer unit is intended for use in the domestic / private environment only, not in commercial situations.
- This electric bottle / food warmer unit cannot be used for any purpose other than what it has been designed for, which is warming up baby milk or baby food.

Model No.: NW1091 (HB-011) Rated Power : 80W Voltage : 220-240V, 50/60Hz

Imported Japanese PTC ceramic heating technology, accurate, constant temperature, efficient and is energy saving.

ADVACARE (Pty) LTD. t/a Snookums POSTNET SUITE 265 PRIVATE BAG X13 BRACKENFELL 7561 SOUTH AFRICA www.snookums.co.za info@advacare.co.za Customer Care Line : 086 101 8885